



Tile Flashing System

1. Locate rafter in the typical manner. Remove tile.
2. Pre-drill lag bolt holes through base and backfill holes with RainBuster.
3. Place base in proper location and install lag bolts with washers in predrilled locations.
4. Apply RainBuster over screw heads and along leading upslope edge of the base.
5. Install Flashing. *Always install one flashing prior to installing fasteners to verify layout*
6. Attach compression bracket with provided 5/16"-18 x 1.25" Hex Bolt and EPDM bonded washer, torque to 120-150 in-lb.
7. Re-align adjacent tiles as necessary to create a watertight roof connection.

