



## SimpleGrip-SQ

1. Locate the rafters and mark the installation position for each mount. Predrill a single 1/8" hole into roof to confirm rafter location.\*  
Surface Prep: Surface must be dry and clear of all debris. Use a dry brush or compressed air to clear area.
2. Remove release paper from one side of Roof Level Mastic. Place and roll onto roofs surface. \*
3. Remove second side of release paper and place SimpleGrip-SQ base onto center of Roof Level Mastic.
4. Install fasteners. A minimum 2 fasteners into rafter at opposite sides of base plate.
5. Place Upper Level Mastic over perimeter of SimpleGrip Base.
6. Complete the assembly by placing (1) Compression Plate fitted with GreenFasten EPDM bushing, (2) EcoFasten bracket or Rock-It Slide, (3) EPDM bonded washer and (4) Flange nut on SimpleGrip-SQ Base Stud.
7. Torque Flange Nut to 100-140 inch-pounds.

\* The mounts should be attached to the 2x rafters with a minimum penetration of 2" into the center of each of the 2x's.

\* Ambient air temp should be above 40 degrees F or use EternaPrime Primer down to -20 degrees F.

**SimpleGrip-SQ was designed for installation on roofs between 0.5:12 and 3:12 pitch**

 **EcoFasten Solar**<sup>®</sup>  
[www.ecofastensolar.com](http://www.ecofastensolar.com)