



Tile Flashing System

1. Locate rafter in the typical manner. Remove tile.
2. Remove clear film from butyl tape and align edges of base with edges of butyl tape. Press down firmly on the tile base.
3. Predrill lag bolt holes through base and butyl tape.
4. Remove release paper from bottom of butyl tape. Place base in proper location and press down firmly. Backfill holes with sealant. Install lag bolts in predrilled locations.
5. Install Flashing. *Always install one flashing prior to installing fasteners to verify layout*
6. Attach compression bracket with provided 5/16"-18 x 1.25" Hex Bolt and EPDM bonded washer, torque to 120-150 in-lb.
7. Re-align adjacent tiles as necessary to create a watertight roof connection.