

Tile Hook Flashing

1. Remove the tile at the location of the to be installed tile hook.

2. Install third party tile hook according to manufacturer's installation instructions.

3. Replace removed tile with the Tile Hook Flashing. Nail the flashing to the batten with 1-2 nails as seen fit to prevent the flashing from moving.

EcoFasten Solar®
www.ecofastensolar.com

EcoFasten Solar® All content protected under copyright. All rights reserved. 01/13/16
EcoFasten Solar products are protected by the following U.S. Patents: 8,151,522 / 8,153,700 / 8,181,398 / 8,166,713 / 8,146,299 / 8,209,914 / 8,245,454 / 8,272,174 / 8,225,557 / 9,010,038 / 9,134,040 / 9,175,478 / 9,212,833