



EcoFasten

For Installers. By Installers.



TILE HOOK FLASHING

**STAND ALONE REPLACEMENT
TILE FLASHING FOR TILE HOOKS**

INSTALLATION GUIDE

REVISION: 12/18/23

VERSION: V2.0

TILE HOOK FLASHING

INSTALLATION GUIDE

**EcoFasten**

For Installers. By Installers.

CLICKING THE PAGE NAME WILL TAKE YOU TO THAT PAGE

[**TABLE OF CONTENTS**](#) **PAGE 01**

[**FEATURES & BENEFITS**](#) **PAGE 02**

[**COMPONENTS**](#) **PAGE 03**

[**INSTALLATION**](#) **PAGE 04**

[**LINE DRAWINGS**](#) **PAGE 05**

[**SPECIFICATIONS**](#) **PAGE 08**


TABLE OF CONTENTS

TILE HOOK FLASHING

INSTALLATION GUIDE



EcoFasten
For Installers. By Installers.



TILE HOOK FLASHING

Tile Hook Flashing is a standalone flashing that can be used in conjunction with our ClickFit System or other third-party tile hooks. The flashing replaces a concrete tile, so there is no need for the cutting, drilling, or grinding of tiles. The flashing comes in three shapes that are made to fit most tile profiles.

FEATURES

- Works with third party tile hooks
- Replaces a tile, extra tile can be used to replace broken tiles
- Available in Flat, S and W-shaped tile profiles
- Sierra Tan finish blends with most tile roofs

FEATURES + BENEFITS


TILE HOOK FLASHING

INSTALLATION GUIDE



EcoFasten
For Installers. By Installers.

SYSTEM COMPONENTS



- 1. W-SHAPED TILE HOOK FLASHING**
- 2. S-SHAPED TILE HOOK FLASHING**
- 3. FLAT TILE HOOK FLASHING**

COMPONENTS


TILE HOOK FLASHING

INSTALLATION GUIDE




EcoFasten
For Installers. By Installers.


INSTALLING TILE HOOK FLASHING



Remove the tile at the location where the tile hook is to be installed.



Install EcoFasten's ClickFit Tile hook or third party tile hook according to hook manufacturer's installation instructions.



Replace the removed tile with appropriate shaped Tile Hook Flashing. It is permissible to nail the flashing to the batten using 1-2 nails as seen fit to prevent the flashing from moving.

INSTALLATION


TILE HOOK FLASHING



INSTALLATION GUIDE



EcoFasten
For Installers. By Installers.

CUT SHEET: TILE HOOK FLASHING - S

	8	7	6	5	4	3	2	1	
F	REVISIONS								F
	REV.	DESCRIPTION	ECO	DATE	APPROVED				
	01	INITIAL RELEASE SUPERCEDES TILE FLASHING S	5169	8/20/2019	ALM				
E	CONFIGURATION TABLE								E
	PART NUMBER	MATERIAL	THICKNESS	SURFACE TREATMENT	WEIGHT				
	250007-01	ALUMINUM, 1100-H12	0.80 +0.03/-0.00	PRE-PAINTED ONE SIDE, SIERRA TAN, KYNAR 500 PVDF OR VALSPAR FLOUROPOLYMER OR EQUIVALENT, MUST MEET AAMA2605	511.8 g				
D	 <p style="margin-left: 200px;">FAR SIDE OF THIS SURFACE IS BONDING SURFACE KEEP COMPLETELY FREE OF PAINT AND OTHER NON-CONDUCTIVE MATERIALS.</p> <p style="margin-left: 200px;">PAINT/COAT THIS SIDE ONLY (WHEN REQUIRED) MINIMAL OVERSPRAY ON FAR SIDE ACCEPTABLE.</p>								D
C									C
B									B
A									A
8	7	6	5	4	3	2	1		

<p>UNLESS OTHERWISE STATED: DIMENSIONS ARE IN MILLIMETERS INCHES ARE IN []</p> <p>TOLERANCES: X.XX ± 0.25 X.X ± 0.2 ANGULAR ± 2.0</p> <p>BEND RADI 1-2X THICKNESS CORNER RADI 1.5 MAX</p> <p>THIRD ANGLE PROJECTION</p>  <p>INTERPRET DRAWING PER ASME Y14.35-2014 AND ASME Y14.5-2009</p> <p>DIGITAL PRODUCT DEFINITION DATA PER ASME Y14.41-2012 DO NOT SCALE</p>	<p>© COPYRIGHT ECOFASTEN SOLAR. ALL RIGHTS RESERVED. THE INFORMATION DISCLOSED HEREIN IS DEEMED TO BE CONFIDENTIAL, PROPRIETARY, AND A TRADE SECRET OF ECOFASTEN SOLAR. THE INFORMATION MAY NOT BE REPRODUCED, REPRODUCED, OR DISCLOSED WITHOUT THE WRITTEN CONSENT OF ECOFASTEN SOLAR.</p> <p>SEE CONFIG TABLE</p> <p>SURFACE TREATMENT (SEE NOTE 3) SEE CONFIG TABLE</p> <p>WEIGHT (g)</p>	<p style="text-align: center;"> An ESDEC Company</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">DRAWN BY</td> <td style="text-align: center;">APPROVED BY</td> <td style="text-align: center;">DATE</td> </tr> <tr> <td style="text-align: center;">R. VAN LAW</td> <td style="text-align: center;">A. MORANO</td> <td style="text-align: center;">8/20/2019</td> </tr> </table> <p style="text-align: center;">DESCRIPTION TILE REPLACEMENT FLASHING - S TILE</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">DRAWING NUMBER</td> <td style="text-align: center;">REVISION</td> </tr> <tr> <td style="text-align: center;">250007</td> <td style="text-align: center;">01</td> </tr> </table> <p style="text-align: center;">SIZE: A3 SCALE: 2:1 SHEET: 1 OF 2</p>	DRAWN BY	APPROVED BY	DATE	R. VAN LAW	A. MORANO	8/20/2019	DRAWING NUMBER	REVISION	250007	01
DRAWN BY	APPROVED BY	DATE										
R. VAN LAW	A. MORANO	8/20/2019										
DRAWING NUMBER	REVISION											
250007	01											

LINE DRAWINGS

TILE HOOK FLASHING

INSTALLATION GUIDE



CUT SHEET: TILE HOOK FLASHING - W

CONFIGURATION TABLE					REVISIONS				
PART NUMBER	MATERIAL	THICKNESS	SURFACE TREATMENT	WEIGHT	REV.	DESCRIPTION	ECO	DATE	APPROVED
250008-01	ALUMINUM, 3003-H14 (H12)	0.80 +0.03/-0.00	PRE-PAINTED ONE SIDE, SIERRA TAN, KYNAR 500 PVDF OR VALSPAR FLOUROPOLYMER OR EQUIVALENT, MUST MEET AAMA2605	407.9 g	01	INITIAL RELEASE SUPERCEDES TILE FLASHING W	5170	8/20/2019	ALM

FAR SIDE OF THIS SURFACE IS A BONDING SURFACE
KEEP COMPLETELY FREE OF PAINT AND OTHER
NON-CONDUCTIVE MATERIALS.

PAINT/COAT THIS SIDE ONLY (WHEN REQUIRED)
MINIMAL OVERSPRAY ON FAR SIDE ACCEPTABLE

UNLESS OTHERWISE STATED: DIMENSIONS ARE IN MILLIMETERS INCHES ARE IN [] TOLERANCES: X.XX ± 0.25 X.X ± 0.5 ANGULAR ± 2.0 BEND RADIUS - 2X THICKNESS CORNER RADIUS - 1.5 MAX	© COPYRIGHT © COASTAL KOLAK, ALL RIGHTS RESERVED. THE INFORMATION DISCLOSED HEREIN IS INTENDED TO BE CONFIDENTIAL, PROPRIETARY, AND A TRADE SECRET OF ECOFASTEN/ESDEC. THIS INFORMATION MAY NOT BE USED, REPRODUCED, OR DISCLOSED WITHOUT THE EXPRESS WRITTEN CONSENT OF ECOFASTEN/ESDEC. MATERIAL: SEE CONFIG TABLE SURFACE TREATMENT (SEE NOTE 3): SEE CONFIG TABLE WEIGHT (G): SEE CONFIG TABLE	DRAWN BY: R. VAN LAW APPROVED BY: A. MORANO DATE: 8/20/2019 DESCRIPTION: TILE REPLACEMENT FLASHING, W TILE DRAWING NUMBER: 250008 REVISION: 01 SIZE: A3 SCALE: 1:2 SHEET: 1 OF 2
---	---	--

LINE DRAWINGS

TILE HOOK FLASHING

INSTALLATION GUIDE



EcoFasten
For Installers. By Installers.

CUT SHEET: TILE HOOK FLASHING - FLAT

CONFIGURATION TABLE					REVISIONS				
PART NUMBER	MATERIAL	THICKNESS	SURFACE TREATMENT	WEIGHT	REV.	DESCRIPTION	ECO	DATE	APPROVED
F 250006-01	ALUMINUM, 1100-H12	0.80 +0.03 / -0.00	PRE-PAINTED ONE SIDE, SIERRA TAN, KYNAR 500 PVDF OR VALSPAR FLOUROPOLYMER OR EQUIVALENT, MUST MEET AAMA2605	511.8 g	01	INITIAL RELEASE SUPERCEDES FLAT TILE F	5168	8/19/2019	A. MORANO

<p>UNLESS OTHERWISE STATED: DIMENSIONS ARE IN MILLIMETERS INCHES ARE IN ()</p> <p>TOLERANCES: X.XX ± 0.25 X.X ± 0.10 ANGULAR ± 0.0</p> <p>BEND RADI 1-2X THICKNESS CORNER RADI 1.5 MAX</p> <p>THIRD ANGLE PROJECTION</p> <p>INTERPRET DRAWING PER ASME Y14.3-2014 AND ASME Y14.43-2009</p> <p>DIGITAL PRODUCT DEFINITION DATA-PDF ASME Y14.41-2012 DO NOT SCALE</p>	<p>© COPYRIGHT ECOFASTEN GLOBAL. ALL RIGHTS RESERVED. THE INFORMATION DISCLOSED HEREIN IS INTENDED TO BE CONFIDENTIAL, PROPRIETARY AND A TRADE SECRET OF ECOFASTEN GLOBAL. THE INFORMATION MAY NOT BE REPRODUCED, REPRODUCED OR DISCLOSED WITHOUT THE EXPRESS WRITTEN CONSENT OF ECOFASTEN GLOBAL.</p> <p>SEE CONFIG TABLE</p> <p>SEE CONFIG TABLE</p> <p>SEE CONFIG TABLE</p> <p>SEE CONFIG TABLE</p>	<p style="text-align: center;"> EcoFasten An ESPEC Company</p> <p>DRAWN BY: R. VAN LAW APPROVED BY: A. MORANO DATE: 8/19/2019</p> <p>DESCRIPTION: TILE REPLACEMENT FLASHING, FLAT TILE F</p> <p>DRAWING NUMBER: 250006 REVISION: 01</p> <p>SHEET: 1 OF 2</p>
--	--	--

LINE DRAWINGS

TILE HOOK FLASHING

INSTALLATION GUIDE



EcoFasten
For Installers. By Installers.

SYSTEM COMPONENTS

1. Flashing:

Available in three heights for Flat, W and S-shaped tile profiles. Consists of (1) aluminum flashing with top side pre-painted Sierra Tan Kynar finish.

DELIVERY / STORAGE / HANDLING

Inspect material upon delivery. Notify manufacturer within 24 hours of any missing or defective items. Keep material dry, covered and off the ground until installed.

PATENTS

Visit www.efpatents.com for patent information.

DESIGN REQUIREMENTS

1. Fasten to batten using two nails as seen fit if desired.
3. It is important to design new structures or assess existing structures to make sure they withstand retained loads.

TILE HOOK FLASHING

INSTALLATION GUIDE



EcoFasten
For Installers. By Installers.

EXAMINATION

1. Substrate: Inspect structure on which brackets are to be installed and verify that it will withstand any additional loading that may be incurred.
2. Notify General Contractor of any deficiencies before installing EcoFasten Solar brackets.
3. Verify that roofing material has been installed correctly prior to installing solar attachment bracket.

INSTALLATION

Comply with architectural drawings and project engineer's recommendation for location of system. Comply with Manufacturer's written installation instructions for installation and layout.

SPECIFICATIONS

PAGE
09